
incite fire



The **QE20-FP2011 8Zone/8WIP Extender Module** may be used as an expansion user interface module, or as a replacement for an existing module in the field.

This module comes complete with 1 x 8zone board and 1 x 8WIP board already fitted.

Each kit contains:


- 1 x Extender user interface module
- 1 x QBus 4way power/comms loom, 475mm long
- 4 x M4 x 10mm mounting screws
- 2 x Slide in labels for zone/WIP
- 2 x cable ties
- 1 x Earth loom, 450mm long
- 1 x Installation guide


QE20-FP2011 QE20 8WIP/8Zone Extender Module Kit

General Specifications*:

Operating voltage:	_18-32Vdc
Operating current:	_5mA typ @ 24V all LEDs off, each PCB 32mA typ @ 24V all LEDs on, each PCB
Operating Temp:	5°C to +45°C, 10-93% RH
Address:	_0 - 28 supported
Qty per QE20:	_28 x 8Z & 28 x 8WIP display boards per QE20. 224 zones

*Detailed specifications listed on QE20-FP2011 Installation Guide





All specifications and other information shown were current as of document revision date and are subject to change without notice. Ver 1.01 08/2024